


How to unlock OS on ROS.


1. Go to “change user” on ROS and change user mode as below.

User ID : Kongsberg, PW : It will be informed separately.



2. Go to “maintenance” and check whether the mode is “lock OS” or “unlock OS” on service as below.
If “Unlock OS” is alive as below capture, please change it correctly. It is required to put in correct password.

Password : Norcontrol



3. Below is Unlock mode status. You can access windows7 from now on.

